

3-7	Campagnolo® Hub Service .....	41
3-7.1	Disassembly .....	41
3-7.3	Assembly .....	44
3-7.4	Adjustment .....	43
3-8	Freehub Removal & Installation .....	46

**CHAPTER FOUR - WHEEL TRUING**

4-1	Truing Procedures .....	52
4-1.1	Lateral Truing .....	54
4-1.2	Radial Truing .....	55
4-1.3	Wheel Centering (Dishing) .....	56
4-1.4	Spoke Tension .....	58
4-2	Replacing Broken or Damaged Spokes .....	59
4-3	Wheel Wear, Damage & Repair .....	60

**CHAPTER FIVE - PEDALS, CRANKS, & BOTTOM BRACKET**

5-1	Pedals and Riding Shoes .....	64
5-1.1	Pedal Removal .....	64
5-1.2	Pedal Installation .....	65
5-1.3	Damage to Crank Pedal Threads .....	65
5-2	Cranksets .....	66
5-2.1	Crank Removal-Square Hole .....	66
5-2.2	Crank Installation-Square Hole .....	68
5-2.3	Crank Removal-Splined Hole .....	69
5-2.4	Crank Installation-Splined Hole .....	70
5-3	Bottom Bracket Bearings & Spindle .....	71
5-4	Bottom Bracket Tool Selection .....	73
5-5	Cartridge Bottom Brackets .....	73
5-5.1	Cartridge Bottom Bracket Removal .....	75
5-6	Adjustable Bottom Brackets .....	75
5-6.1	Adjustable Bottom Bracket Removal .....	75
5-6.2	Adjustable Bottom Bracket Installation .....	79
5-6.3	Adjustable Bottom Bracket Adjustment .....	79
5-7	External Bearing Crankset Systems .....	79
5-7.1	Bearing Installation .....	80
5-7.2	Crank Installation and Removal of External Bearing Crankset .....	81
5-7.3	Installation and Removal of External Bearing Crankset .....	81
5-7.4	Crank Installation and Removal of External Bearing Crankset .....	82
5-8	Chainrings .....	83
5-8.1	Chainring Replacement .....	84

**CHAPTER SIX - CHAINS**

6-1	Chain Sizing .....	88
6-2	Chain Cutting .....	90
6-2.1	Shimano® Chain Service With Replacement Rivet .....	90
6-2.3	Chain With "Master-Link" .....	93
6-2.4	Chain With Reusable Rivet .....	93
6-3	New Chain Installation on Derailleur Bikes .....	94
6-4	Tight Link Repair .....	95
6-5	Chain Wear and Damage .....	96
6-6	Chain Cleaning .....	97
6-7	Chain Lubrication .....	98

**CHAPTER SEVEN - DERAILLEUR SYSTEMS**

7-1	Cable System .....	102
7-1.1	Housing Length .....	103
7-1.2	Cable Lubrication .....	104
7-2	Shift Levers .....	105
7-2.1	Flat Bar Trigger Shifters .....	105
7-2.2	Twist-grip Shifters .....	106
7-2.3	Above-the-Bar Shifters .....	107
7-2.4	Drop Bar Integral Brake & Gear Shifters .....	107
7-2.5	Down Tube Shifters .....	108
7-2.6	Bar End Shifters .....	108
7-3	Front Derailleur .....	110
7-3.1	Derailleur Cable Attachment .....	111
7-3.2	Derailleur Cable Adjustment .....	112
7-3.3	Derailleur Cable Adjustment (Drop Bar Bikes) .....	114
7-3.4	Derailleur Cable Adjustment (Flat Bar Bikes) .....	114
7-3.5	Derailleur Cable Adjustment (Road Bikes) .....	114
7-3.6	Derailleur Cable Adjustment (Mountain Bikes) .....	114
7-3.7	Front Derailleur Adjustment .....	115
7-4	Rear Derailleur .....	116
7-4.1	Derailleur Capacity & Maximum Sprocket Size .....	116
7-4.2	Derailleur Cable Attachment .....	117
7-4.3	Limit Screw Adjustment .....	119
7-4.4	B-Screw Adjustment .....	119
7-4.5	Index Adjustment .....	121
7-5	Chainline .....	123
7-6	Derailleur Hanger Alignment & Repair .....	125
7-7	Derailleur Inspections .....	125
7-8	Troubleshooting .....	126

